



REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	847308	1	Starter motor		24V
				030-1150	
2	953486	3	Stud		
3	942336	3	Spring washer		
4	955827	3	Nut		
5		1	ALTERNATOR AND INSTALLATION COMPONENTS, LOW LEFT	030-0905	
		1	ALTERNATOR AND INSTALLATION COMPONENTS, LOW RIGHT	030-0910	
6	823416	1	Pressure monitor		
7	823417	1	Hollow screw		
8	957178	2	Gasket		
9	850420	1	Horn		
10	955536	1	Screw		
11	942336	1	Spring washer		
12	843028	1	Spacer sleeve		
13		1	CABLE UNIT		
14		X	· CABLES AND TERMINALS	030-1500	
15	948210	X	Strip clamp		
16		X	· CABLE IRON		
17	11411	1	Ground cable		
18	846695	1	Tachometer sensor		IS USED WHEN ONE OR MORE TACHOMETER SENDER IS CONNECTED
19	925059	1	O-ring		
20	827150	1	Temperature sensor		
	822858	1	Thermo monitor		TEMPERATURE GUARD - AUTOMATIC SUPERVISION
21	11996	1	Gasket		TEMPERATURE SENDER 827150
22	834391	1	Nipple		
23	180759	1	Plug		
24	843231	1	Oil pressure sensor		
25	848367	1	Pressure switch		
26		1	BATTERY BOX AND INSTALLATION COMPONENTS	030-1475	
27		1	INSTRUMENT PANEDL AND INSTALLATION COMPONENTS	030-1450	
					POWER PACK
		1	INSTRUMENT PANEL INSTALLATION COMPONENTS		POWER PACK
28		1	INSTRUMENT PANEL AND INSTRUMENTS	030-1462	
29	823409	1	Tachometer		
34		1	ELECTRICAL BOX AND INSTALLATION COMPONENTS	030-0337	
35	847051	1	Cable trunk		ENGINE WITH SINGLE ALTERNATOR
	847074	1	Cable trunk		STARTER - ALARM SYSTEM - STOP SOLENOID

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
39	1581232	1	Level indicator		
40	11994	1	Gasket		
41	1501618	1	Relay		24V
42	847409	1	Bracket		
43	846728	1	Brace		
44	955120	3	Screw		
45		1	STARTING HEATER AND INST. COMPONENTS	030-1285	