



TWD1630P

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	866372	1	Injection pump		
	3803729	1	Injection pump, exch		Exchange unit
				1494	
2	479775	1	· Overflow valve		
3	15304	1	· Gasket		ALT
	969011	1	· Gasket		ALT
4	965189	4	Flange screw		
5	190509	2	Washer		
6	477173	1	Pressure equalizer		
7	969011	1	Gasket		
8	862997	1	Oil feed pipe		
9	48634	1	Hollow screw		
10	947281	2	Gasket		
11	952623	1	Clamp		
12	942078	1	T-nipple, cylinder block		
13	1543721	2	Bracket		
14	954356	1	Cap nut		
15	954364	1	Fitting		
16	1543962	1	Oil return pipe		
17	48634	1	Hollow screw		
18	947281	2	Gasket		
19	952623	1	Clamp		
20	956092	2	Screw		
21	25167	1	Hollow screw, cylinder block		
22	969011	2	Gasket		
23	74033	1	Hollow screw		
24	947620	2	Gasket		
25	862566	1	Leak-off line		
26	16496	1	Hollow screw		
27	969011	2	Gasket		
28	479979	1	Plug		
29	849211	1	Fuel pipe, return		
30	849210	1	Fuel pipe, feed		
31	25167	1	Hollow screw		
32	969011	2	Gasket		
33	865737	2	Fuel hose		
34	956969	4	· Ferrule		
35	956983	4	· Nut		
36	402404	2	Clamp		
37	956094	1	Screw		
38	955892	1	Washer		
39	945407	1	Flange nut		
40	849213	1	Fuel pipe		
41	849212	1	Fuel pipe		
42	404279	4	Clamp		
43	956095	2	Screw		
44	955892	2	Washer		
45	955781	2	Nut		
46	25167	4	Hollow screw		
47	969011	8	Gasket		
48	1676832	1	Filter housing		
49	471177	1	· Screw, air venting		
50	947620	1	· Gasket		
51	849769	1	Bracket		
52	965185	2	Flange screw		
53	3825133	2	Fuel filter		(466987)
54	6638088	2	· Gasket		
55	968062	3	Plug		